Microwave Bracket Install Guide

All Microwave brackets are supplied with pre-drilled mounting holes.

- To install the bracket to the microwave there are 2 holes on the right and 3 on the left. We recommend using a 6g self-drilling pan head no longer than 15mm.

- Place the microwave on a flat surface and place the bracket around it so the bottom of the bracket is sitting flush with the microwave.

- Install the bracket over the microwave and keep the face flush with the microwave. Install the 2 screws on the right-hand side, and then the 3 screws on the left.

- Put the microwave and bracket into the position to install to the cabinetry.

- Open the microwave door and you will find 2 holes in the top and 2 holes in the bottom. These holes are for securing to the cabinet.

Alternatively, you can also predrill a hole in each corner of the bracket on the face and use these to secure to the cabinet.