



MODELS



|                      | Europe |   | America    |   | Asia, Pacific |
|----------------------|--------|---|------------|---|---------------|
|                      | B/W    | S | B/W/BT/BTF | S | B/C/S         |
| 12/24 V $\text{---}$ | ●      | ● | ●          | ● | ●             |
| 100 – 240 V $\sim$   | -      | - | -          |   | -             |
| R600a                |        |   | -          | - |               |
| R1234yf              | -      |   |            | - | -             |


DIMENSIONS











|               | A (mm/in) | B (mm/in) | C (mm/in) |
|---------------|-----------|-----------|-----------|
| NRXD0015/1015 | 380/15.0  | 250/9.8   | 510/20.1  |
| NRXD0020/1020 | 440/17.3  | 250/9.8   | 564/22.2  |
| NRXD0030/1030 | 440/17.3  | 250/9.8   | 730/28.7  |

|               | W (mm/in)         | H (mm/in)         |
|---------------|-------------------|-------------------|
| NRXD0015/1015 | 390–392/15.3–15.4 | 256–258/10.1–10.2 |
| NRXD0020/1020 | 450–452/17.7–17.8 | 256–258/10.1–10.2 |
| NRXD0030/1030 | 450–452/17.7–17.8 | 256–258/10.1–10.2 |





**Note:** The size is the base for ventilation and also applicable for installation with a frame.









NOTICE







DANGER



AIR FLOW





DC





AC




100 – 240 V  $\sim$





# DETACHING DRAWER








# FIXING








# FRAME



# REINSTALLATION



# INSTALLATION ON WALL



**YOUR LOCAL DEALER**  
dometic.com/dealer

**YOUR LOCAL SUPPORT**  
dometic.com/contact

**YOUR LOCAL SALES OFFICE**  
dometic.com/sales-offices

A complete list of Dometic companies, which comprise the Dometic Group, can be found in the public filings of:  
**DOMETIC GROUP AB** Hemvärnsgatan 15 SE-17154 Solna Sweden