

# **MX8500SD QUICK START GUIDE**

6500 RUNNING WATTS

7000 STARTING WATTS





# ADD OIL: 1.0 Litre SAE 10W-30

Place unit on a flat surface. Remove the oil dipstick. With the funnel supplied add 1.0 Litre SAE 10W-30 oil.Replace dipstick and tighten.



#### **ADD FUEL:**

Fill the fuel tank with clean diesel. Note that the fuel tank capacity is





#### **STARTING THE GENERATOR:**

- 1) Ensure that the generator is placed in a well ventilated area.
- 2) Ensure that there are no electrical appliances plugged into the generator.

# **Battery connection**

Fasten the black negative wire on the negative terminal of the battery











## **PUSH - BUTTON START:**

- 1) Turn the red switch to the "O" position.
- 2) Press & hold the Start Button for 4 seconds and wait for the generator to start.
- 3) Once the generator is running smoothly you can then connect the appliances.

#### CAUTION:

- 1) BE CAREFUL TO NOT OVERLOAD the generator.
- 2) DO NOT PLUG THE GENERATOR DIRECTLY INTO A WALL SOCKET.





## TO STOP:

- 1) Hold down the Remote "STOP" button for 3 seconds.
- 2) Disconnect the appliances from the generator.



**CAUTION!** 

When the generator is not used for a long time for more than one month, it is necessary to disconnect the negative battery wire, or the battery will run out!

#### REVIEW AND UNDERSTAND YOUR OWNERS MANUAL AND ALL WARNINGS BEFORE RUNNING YOUR GENERATOR

from open windows or doors.

#### **ADANGER**



Risk of fire. Check for any fuel overflow or leakage. Stop the engine before refueling.



Generator is a potential source of electric shock. Do not expose to moisture, rain, or snow. Do not operate with wet hands or feet.



Failure to properly ground generator can result in electrocution, especially if the generator is equipped with You could be killed or seriously

**ADANGER** 

Exhaust contains poisonous carbon monoxide gas that can cause unconsciousness or DEATH. Operate in well ventilated, outdoor areas away



hurt if you do not follow the

Operator's Manual instructions

## **ADANGER**

USING A GENERATOR INDOORS CAN KILL YOU IN MINUTES. GENERATOR EXHAUST CONTAINS CARBON MONOXIDE. THIS IS A POISON YOU CANNOT SEE OR SMELL.









ONLY USE OUTSIDE AND OR GARAGE, EVEN IF DOOR | FAR AWAY FROM WINDOWS, AND WINDOWS ARE OPEN. DOORS, AND VENTS.

