

Generac Home Standby Generator - Gas Train installation and instruction sheet.

December 2013 v1.

Each Generac install needs to have a certified gas train fitted; Allpower will supply parts for this gas train.

Kit parts include:

1. 1 x gas filter regulator FRG/2MBCZ DN15
2. 1 x Valve 221616 H30B
3. 1 x coil - Parker L111C1
4. 1 x nut, washer and faceplate for the coil.

The process

- Connect to PLG gas supply sized to provide 2.75kPa at full load
- Load details are available from the Generac generator manual
- Under the Orange lid of the gas regulator is the OPSO (over-sized shutoff) and the UPSO (under-pressure shut off) – push to rest.
- UPSO features can be removed. Undo inner spring and remove.
- Solenoid to be wired with existing solenoid on machine (12v DC)
- Instruction by Combustion Control Ltd 09 634 1610 (Brett Oldfield)

